

DaVinci Deluxe 1.0.44 — Cloud Edition

SUPPORTED ECU LIST — MODULES & TUNING

Latest update: 06 September 2026

49
BRANDS

1206
ECUs

28
MODULES

22
TUNING OPTIONS

CAPABILITIES — EVERY MODULE & TUNING OPTION IN THE CATALOG

Performance Tuning (22)

Stage1Stage2E85 ConversionVMAXStage1+Pops&BangsTorque MonitorStage3Exhaust Valve OFFHardCutRPM Soft Limiter Removal

Launch Control ActivationSport Displays CalibrationPops&Bangs (Switchable)HotstartCylinder On Demand OFFGearbox TuningHot Start FixAnti-Lag

Boost IncreaseEco TuneRev Limiter Raise

Emissions & Diagnostics (28)

EGRDPFLAMBDA DTC OffCAT/KATFLAPS (Swirl)TVAAdblueEVAPNOXStart-StopMAFReadiness CalibrationGPF/OPFSAPWater Pump

Active Grill ShutterGlow PlugDecatOil Pressure FixEGT OffAGSCold Start DeleteIgnition CutLIMPMultimapSmoke Limiter OffTVA Off

Immo & Security (4)

Immo Off (FLASH)Immo Off (EPROM)TPROTFCALock

Aston Martin

1 ECU

GEN1024K

Stage1

BMW

1 ECU

MD1CS001

Stage1DPF

BMW - Mini

95 ECU

DCM3.7

Stage1

ECU TYPE: BOSCH EDC17C06

DPF

EDC15

Pops&BangsStage1Stage1+Stage2Stage3

VMAXDPFEGRFLAPS (Swirl)MAF

EDC15C4

Pops&BangsStage1Stage1+Stage2Stage3

Torque MonitorVMAXAdblueDPFDTC OffEGR

Immo Off (EPROM)Immo Off (FLASH)

EDC15C6

Stage1

EDC15P

Stage1Stage2

EDC16

Stage1

EDC16C1

EGR

EDC16C31

E85 ConversionGearbox TuningHardCutPops&Bangs

Stage1Stage1+Stage2Stage3VMAXAdblue

DPFDTC OffEGRFLAPS (Swirl)LAMBDA MAF

Smoke Limiter OffTVAImmo Off (FLASH)

EDC16C35

E85 ConversionHardCutStage1Stage1+Stage2

Stage3VMAXDPFDTC OffEGRFLAPS (Swirl)

LAMBDA MAF TVA

EDC16CP35

E85 ConversionPops&BangsStage1Stage1+

Stage2Stage3VMAXDPFDTC OffEGR

FLAPS (Swirl)LAMBDA MAF TVA

EDC16CP39

Stage1

EDC17

Stage1Stage2AdblueCAT/KATDPFDTC OffEGR

EDC17C06

E85 ConversionStage1Stage1+Stage2Stage3

Torque MonitorVMAXAdblueDPFEGRFLAPS (Swirl)

LAMBDA MAF NOXStart-StopImmo Off (FLASH)

EDC17C41

E85 ConversionHardCutRPM Soft Limiter Removal

Sport Displays CalibrationStage1Stage1+Stage2

Torque MonitorVMAXAdblueDPFDTC OffEGR

FLAPS (Swirl)LAMBDA NOXReadiness Calibration

Start-StopTVA

EDC17C41BENCHNR

EGR

EDC17C42

DPF

EDC17C50

Stage1Stage2VMAXAdblueDPFDTC OffEGR

FLAPS (Swirl)

EDC17C50-C56

HardCutLaunch Control ActivationPops&Bangs

RPM Soft Limiter RemovalSport Displays Calibration

Stage1Stage1+Stage2Stage3Torque Monitor

VMAXAdblueDPFDTC OffEGRFLAPS (Swirl)

LAMBDA NOXReadiness CalibrationStart-StopTVA

Immo Off (FLASH)

EDC17C56

E85 ConversionStage1Stage2DPFDTC OffEGR

EDC17C76

VMAXDPFEGRFLAPS (Swirl)LAMBDA NOXTVA

EDC17CP02

HardCutPops&BangsStage1Stage1+Stage2

Stage3Torque MonitorVMAXDPFDTC OffEGR

FLAPS (Swirl)LAMBDAReadiness CalibrationStart-Stop

TVA TPROT

EDC17CP09

Stage1Stage1+Stage2Stage3Torque Monitor

VMAXAdblueDPFDTC OffEGRFLAPS (Swirl)

LAMBDAReadiness CalibrationStart-StopTVA

EDC17CP45

E85 ConversionStage1Stage2AdblueDPFDTC Off

EGR TVA

EDC17CP45-CP49

Sport Displays CalibrationStage1Stage1+Stage2

Torque MonitorVMAXAdblueDPFDTC OffEGR

FLAPS (Swirl)LAMBDA NOXReadiness Calibration

Start-StopTVAImmo Off (FLASH)

EDC17CP49

Stage1Stage2AdblueDPF

EMS2

Stage1

MD1CP002	Sport Displays Calibration	Stage1	Stage2	Stage3
	Torque Monitor	VMAX	Adblue	DPF
	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration
MD1CP032	DPF	EGR	FLAPS (Swirl)	LAMBDA
	Readiness Calibration	TVA		
MD1CS001	Sport Displays Calibration	Stage1	Torque Monitor	
	VMAX	Adblue	DPF	EGR
	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration
MD1CS001BENCHNR	Adblue			
ME7	E85 Conversion	Stage1		
ME7.1	E85 Conversion	Stage1		
ME7.1-ME7.1.1	Stage1	CAT/KAT	DTC Off	LAMBDA
ME7.2	E85 Conversion	Stage1	Stage2	VMAX
ME9	E85 Conversion	Stage1	Stage2	VMAX
	DTC Off			
ME9.0	E85 Conversion	Stage1		
ME9.1	E85 Conversion	Stage1		
ME9.2	E85 Conversion	Stage1	VMAX	DTC Off
ME9.2.2	E85 Conversion			
ME9.4	E85 Conversion	Stage1	DPF	
ME9.6	Stage1			
ME9.8	Stage1			
ME9.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+
	Stage2	VMAX	CAT/KAT	DTC Off
	LAMBDA			
MED17	E85 Conversion	Stage1	Stage2	CAT/KAT
	EGR			
MED17.1.1	E85 Conversion	Stage1	Stage2	
MED17.2	E85 Conversion	Stage1	Stage2	
MED17.2.2	E85 Conversion	Stage1		
MED172	E85 Conversion	Stage1		
MED9	E85 Conversion			
MED9.1.5	E85 Conversion	Stage1		
MEV17.2	E85 Conversion			
MEV17.2.2	E85 Conversion			
MEV17.4	E85 Conversion	Stage1		
MEV17.4.6	E85 Conversion			
MEV172	E85 Conversion	Stage1		
MEV1746	E85 Conversion	Stage1		
MEV9.1	E85 Conversion			
MEV9.2	E85 Conversion			
MEV9.4.6	E85 Conversion			
MEV946	E85 Conversion	Stage1		
MEVD17.2	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	
	Stage1	Stage1+	Stage2	VMAX
	CAT/KAT	DPF		
	DTC Off	FLAPS (Swirl)	LAMBDA	
MEVD17.2.	Stage1	Stage2	CAT/KAT	
MEVD17.2.2	Stage1			
MEVD17.2.3	Pops&Bangs	Sport Displays Calibration	Stage1	
	Stage1+	Stage2	VMAX	CAT/KAT
	DTC Off	EVAP		
	LAMBDA	Readiness Calibration	SAP	Start-Stop
MEVD17.2.4	Pops&Bangs	Sport Displays Calibration	Stage1	Stage2
	VMAX	CAT/KAT	EVAP	LAMBDA
	Readiness Calibration			

MEVD17.2.5	Pops&Bangs	Sport Displays Calibration	Stage1	Stage2
	VMAX	CAT/KAT	FLAPS (Swirl)	LAMBDA
	Readiness Calibration	Start-Stop		
MEVD17.2.6	Pops&Bangs	Sport Displays Calibration	Stage1	
	Stage1+	Stage2	VMAX	CAT/KAT
	LAMBDA			
MEVD17.2.8	Pops&Bangs	Pops&Bangs (Switchable)		
	Sport Displays Calibration	Stage1	Stage2	
	Torque Monitor	VMAX	CAT/KAT	LAMBDA
	Readiness Calibration			
MEVD17.2.84	Stage1			
MEVD17.2.9	Pops&Bangs	Pops&Bangs (Switchable)		
	Sport Displays Calibration	Stage1	Stage1+	Stage2
	Torque Monitor	VMAX	CAT/KAT	LAMBDA
	Readiness Calibration	Start-Stop		
MEVD17.2.95	Stage1	Stage2		
MEVD17.2.97	Stage1			
MEVD17.2.98	Stage1			
MEVD17.2.G	Pops&Bangs	Pops&Bangs (Switchable)		
	Sport Displays Calibration	Stage1	Stage2	VMAX
	CAT/KAT	DPF	FLAPS (Swirl)	GPF/OPF
	LAMBDA	Start-Stop		
MEVD17.2.H	Pops&Bangs	Sport Displays Calibration	Stage1	
	Stage1+	Stage2	Torque Monitor	VMAX
	CAT/KAT			
	LAMBDA	Start-Stop		
MEVD17.8.4	Stage1			
MG1CS003	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	
	Pops&Bangs (Switchable)	Sport Displays Calibration		
	Stage1	Stage1+	Stage2	VMAX
	CAT/KAT	DPF		
	DTC Off	EVAP	FLAPS (Swirl)	GPF/OPF
	LAMBDA	Readiness Calibration	Start-Stop	
MG1CS049	Pops&Bangs	Stage1	VMAX	CAT/KAT
	GPF/OPF			
	Start-Stop			
MG1CS201	Pops&Bangs	RPM Soft Limiter Removal	Stage1	
	Stage1+	Stage2	VMAX	Active Grill Shutter
	CAT/KAT			
	DTC Off	EVAP	FLAPS (Swirl)	GPF/OPF
	LAMBDA	MAF		
MS41	Stage1	Ignition Cut		
MS42	Pops&Bangs	Stage1	Stage1+	Stage2
	Stage3			
	LAMBDA	Immo Off (FLASH)		
MS43	Pops&Bangs	Stage1	Stage1+	Stage2
	CAT/KAT	EVAP		
	LAMBDA	SAP		
MS45	Pops&Bangs	Stage1	CAT/KAT	DTC Off
	EVAP	LAMBDA		
MSD80	E85 Conversion	Pops&Bangs	Pops&Bangs (Switchable)	
	Stage1	Stage1+	Stage2	Stage3
	Torque Monitor			
	VMAX	Adblue	CAT/KAT	DTC Off
	EGR	EVAP		
	FLAPS (Swirl)	LAMBDA	NOX	TVA
MSD81	E85 Conversion	Pops&Bangs	Stage1	Stage1+
	Stage2	VMAX	Adblue	CAT/KAT
	DTC Off	EGR		
	FLAPS (Swirl)	LAMBDA	NOX	TVA
MSD85	Pops&Bangs	Stage1	VMAX	CAT/KAT
	EVAP			
	FLAPS (Swirl)	LAMBDA	NOX	TVA
MSD87	Stage1	VMAX	CAT/KAT	LAMBDA
MSD8X	Stage1	Adblue		
MSS60	Stage1	VMAX	CAT/KAT	DTC Off
	LAMBDA			
MSS6X	Pops&Bangs	Stage1	VMAX	CAT/KAT
	DTC Off	EVAP		
	LAMBDA			

MSV70	E85 Conversion	Pops&Bangs	Stage1	Stage1+				
	Stage2	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	
	LAMBDA	MAF						
MSV80	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	EVAP		
	LAMBDA							
MSV90	Pops&Bangs	Stage1	CAT/KAT	DTC Off	LAMBDA			
ZF8 (GEARBOX)	Stage1	Stage1+						

Bentley		1 ECU
ME7.1.1	Stage1	

Chery

2 ECU

ME7.8

Pops&Bangs

Stage1

Stage2

CAT/KAT

DTC Off

LAMBDA

ME7.9.7

CAT/KAT

LAMBDA

Chrysler

1 ECU

EDC16

Stage1

EGR

Citroën

1 ECU

DCM6.2

Adblue

NOX

DELCO

1 ECU

DELCO E98

DPF

DTC Off

EGR

FCA

61 ECU

9GF (BETA)

Stage1

Adblue

CAT/KAT

DPF

DTC Off

EGR

EVAP

LAMBDA

CRD2.X

FLAPS (Swirl)

EDC15

Stage1

Stage2

DPF

EGR

EDC15C2

Stage1

Stage2

VMAX

DPF

EGR

EDC15C5

Stage1

Stage2

EDC15C6

Stage1

EDC15C7

Stage1

Stage1+

Stage2

Stage3

DTC Off

EGR

EDC16

Stage1

EDC16C08

Stage1

Stage1+

Stage2

DPF

EGR

EDC16C31

E85 Conversion

Stage1

EDC16C31-CP31

Stage1

VMAX

DPF

DTC Off

EGR

FLAPS (Swirl)

LAMBDA

Readiness Calibration

TVA

EDC16C34

Stage1

Stage2

DPF

EGR

EDC16C39

E85 Conversion

Stage1

Stage1+

Stage2

VMAX

CAT/KAT

DPF

DTC Off

EGR

FLAPS (Swirl)

LAMBDA

MAF

TVA

Immo Off (FLASH)

EDC16C8

E85 Conversion

Stage1

EGR

EDC16C9

Stage1

DTC Off

EDC16CP31

Stage1

DPF

EGR

EDC16U31

Stage1

Stage1+

Stage2

DPF

DTC Off

EGR

FLAPS (Swirl)

LAMBDA

TVA

EDC16V2

Stage1

EDC17	Pops&Bangs	Stage1										
EDC17C09	Stage1											
EDC17C10	Stage1	DPF										
EDC17C49	Launch Control Activation	Stage1	Stage1+									
	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR						
	FLAPS (Swirl)	LAMBDA	NOX	TVA								
EDC17C69	E85 Conversion	Stage1	Stage1+	Torque Monitor								
	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)						
	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA							
	Immo Off (FLASH)											
EDC17C79	Stage1	Stage2	Torque Monitor	VMAX								
	Active Grill Shutter	Adblue	DPF	DTC Off	EGR							
	FLAPS (Swirl)	LAMBDA	NOX	TVA								
EDC17CP04	Stage1											
EDC17CP14	Stage1											
EDC17CP27	Stage1	Stage1+	Torque Monitor	DPF	EGR							
	FLAPS (Swirl)	Immo Off (EPROM)										
EDC17CP52	E85 Conversion	Stage1	Torque Monitor	VMAX	Adblue							
	DPF	EGR	LAMBDA	NOX	Immo Off (EPROM)							
GPEC2	Pops&Bangs	VMAX	CAT/KAT	EVAP	LAMBDA							
GPEC2A	Cylinder On Demand OFF	Stage1	CAT/KAT	EVAP								
	FLAPS (Swirl)	LAMBDA	FCA Unlock									
GPEC3	Active Grill Shutter	CAT/KAT	FLAPS (Swirl)	LAMBDA								
GPEC4	Stage1	CAT/KAT	DTC Off	EVAP	LAMBDA							
IAW 45F	Immo Off (FLASH)											
ME17.3.0	E85 Conversion	Pops&Bangs	Stage1	Stage2	DTC Off							
ME17.3.X	Pops&Bangs	Pops&Bangs (Switchable)	Stage1	Stage1+								
	Stage2	CAT/KAT	LAMBDA									
ME2.8	Stage1											
ME3.1	Stage1											
ME7	E85 Conversion											
ME7.3	Stage1											
ME7.3.1	E85 Conversion	Stage1	Stage2									
ME7.3.2	E85 Conversion											
ME7.4.5	Stage1											
ME7.6	Stage1											
ME7.6.2	E85 Conversion											
ME7.9.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX							
	CAT/KAT	LAMBDA										
ME73.1	Stage1	Stage2	Stage3									
ME9.1	Stage1											
MED 17	Pops&Bangs	Stage1	Stage3	CAT/KAT								
MED17.3	E85 Conversion											
MED17.3.0	E85 Conversion											
MED17.3.1	Stage1											
MED17.3.30	Stage1											
MED17.3.5	Stage1											
MED17.6.9	Stage1											
MED7.1.1	Stage1											
MED7.6.2	Stage1											
MJ8DF	HardCut	Stage1	VMAX	Adblue	CAT/KAT	DPF	EGR					
	FLAPS (Swirl)	Glow Plug	LAMBDA	MAF	Start-Stop	TVA						

MJ9DF	Stage1	Stage1+	VMAX	Adblue	DPF	EGR	LAMBDA
	NOX	Start-Stop	TVA	Immo Off (FLASH)			
MJD6F	HardCut	Stage1	Stage2	VMAX	DPF	DTC Off	EGR
	LAMBDA	MAF					
MM8GMF	CAT/KAT	LAMBDA					
SID803A	Stage1	DPF	EGR	EVAP			

Ferrari

2 ECU

MED17.6.9

LAMBDA

MED9.6

Stage1

Stage2

Ford

62 ECU

DCM1.X

Stage1

DTC Off

EGR

DCM3.2

DPF

EGR

DCM3.5

Stage1

Stage1+

VMAX

Active Grill Shutter

DPF

DTC Off

EGR

LAMBDA

DCM6.1

Stage1

Torque Monitor

VMAX

DPF

DTC Off

EGR

DCU

Adblue

DCU102

Stage1

Stage1+

Stage2

VMAX

DPF

DTC Off

EGR

DCU17PC43

Adblue

EDC15

Stage1

Stage2

Stage3

EDC15P

Stage1

Stage2

EDC16

Stage1

Adblue

DPF

EDC16C2

Stage1

EDC16C3

Stage1

Stage1+

Stage2

VMAX

DPF

EGR

FLAPS (Swirl)

Glow Plug

LAMBDA

TVA

EDC16C34

Stage1

Stage2

VMAX

Adblue

DPF

DTC Off

EGR

FLAPS (Swirl)

Glow Plug

LAMBDA

MAF

TVA

Immo Off (FLASH)

EDC16C7

E85 Conversion

Stage1

VMAX

EGR

FLAPS (Swirl)

LAMBDA

TVA

EDC16CP39

Stage1

Stage1+

Stage2

Adblue

DPF

DTC Off

EGR

FLAPS (Swirl)

LAMBDA

TVA

EDC17

Stage1

Stage2

Adblue

CAT/KAT

DPF

DTC Off

FLAPS (Swirl)

EDC17C08

Stage1

EDC17C10

Stage1

Stage2

Torque Monitor

VMAX

Adblue

DPF

EGR

LAMBDA

MAF

TVA

Immo Off (FLASH)

EDC17C46

Stage1

EDC17C70

Stage1

Stage1+

Torque Monitor

VMAX

Adblue

DPF

DTC Off

EGR

FLAPS (Swirl)

LAMBDA

NOX

TVA

EDC17CP05

Torque Monitor

Adblue

DPF

DTC Off

EGR

LAMBDA

NOX

EDC17CP42

Stage1

Stage2

DPF

EGR

LAMBDA

EDC17CP65

Stage1

Adblue

DPF

DTC Off

EGR

FLAPS (Swirl)

LAMBDA

TVA

EMS210X

E85 Conversion

Stage1

CAT/KAT

EMS2204

E85 Conversion

Pops&Bangs

Stage1

CAT/KAT

LAMBDA

EMS24XX

Pops&Bangs

Stage1

VMAX

CAT/KAT

LAMBDA

EMS2510

Stage1

EMS2511

E85 Conversion

MD1CP006	Torque Monitor	Adblue	AGS	DPF	EGR	LAMBDA	LIMP
	Readiness Calibration	Start-Stop					
MD1CS005	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA	
	NOX						
ME17	Stage1						
ME9	E85 Conversion	Stage1					
ME9.0	E85 Conversion	Stage1	Stage2	DTC Off			
ME9.0C	E85 Conversion	Pops&Bangs	Stage1	Stage2	Stage3		
	CAT/KAT	DTC Off	LAMBDA				
MED17	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT		
	DPF	EGR					
MED17.0.1	E85 Conversion	Pops&Bangs	Stage1	Stage1+	VMAX		
	CAT/KAT	DTC Off	EVAP	LAMBDA			
MED17.2	E85 Conversion	Stage1					
MED17.2.2	E85 Conversion	Stage1	Stage2				
MED9	E85 Conversion	Stage1					
MG1CS015	Cylinder On Demand OFF	Pops&Bangs	Stage1	Stage1+			
	VMAX	CAT/KAT	GPF/OPF	LAMBDA			
MG1CS016	Pops&Bangs	Stage1					
MG1CS017	Stage2	CAT/KAT	LAMBDA				
MG1CS018	Pops&Bangs	VMAX	DTC Off				
MG1CS019	Pops&Bangs	Stage1	Stage2	VMAX	DTC Off		
MG1CS028	CAT/KAT	LAMBDA					
SID202-206	Stage1	Stage1+	Stage2	VMAX	DPF	DTC Off	EGR
	LAMBDA	TVA					
SID206	Stage1	Adblue	DPF	DTC Off	EGR		
SID208	E85 Conversion	Eco Tune	Stage1	Stage2			
	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	
	LAMBDA						
SID209	Stage1	DPF	DTC Off	EGR			
SID209-211	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	
	EGR	FLAPS (Swirl)	LAMBDA	NOX	TVA	TVA Off	
SID211	Stage1	VMAX	Adblue	DPF			
SID212	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA	
SID309	E85 Conversion	Stage1	Stage2	VMAX	DPF	DTC Off	
SID802	Stage1						
SID802-804	Stage1	EGR					
SID803	Stage1						
SID803-803A	Stage1	DPF	EGR				
SID804	Stage1	EGR					
SID807	Stage1	DPF	EGR				
SID807-807EV0	Stage1	Stage1+	DPF	EGR			
SID902	Stage1	DPF	EGR				
SIM28	Stage1	CAT/KAT					

Geely

1 ECU

MED17.8.10

Stage1

CAT/KAT

LAMBDA

Great Wall

1 ECU

DCM3.7

DPF

EGR

Hidromek

1 ECU

MD1CS003

Adblue

Honda

17 ECU

EDC15

Stage1

EDC16C31

E85 Conversion Stage1 VMAX DPF DTC Off EGR

EDC16C31-C7

Stage1 Stage1+ Stage2 VMAX DPF EGR
FLAPS (Swirl) LAMBDA TVA

EDC16C7

Stage1

EDC17C01

Stage1 DPF

EDC17C08

Stage1

EDC17C50-CP50

Stage1 Torque Monitor DPF EGR FLAPS (Swirl)
LAMBDA TVA

EDC17C58

E85 Conversion Stage1 DPF EGR

EDC17C58-CP58

Stage1 Stage1+ DPF EGR FLAPS (Swirl) LAMBDA
TVA

EDC17CP06

Stage1 Stage2 DPF EGR

EDC17CP06-16

Stage1 Stage2 Torque Monitor CAT/KAT DPF EGR
FLAPS (Swirl) LAMBDA TVA

EDC17CP16

Stage1

EDC17CP50

Stage1

KEIHIN

Stage1 Stage2 CAT/KAT LAMBDA

ME7.9.3

EGR LAMBDA

MED17.9.3

Pops&Bangs Stage1 Stage2 CAT/KAT DTC Off
LAMBDA

SH7058

Stage1

Hyundai - Kia

32 ECU

CPGDSH2.2X

Pops&Bangs Stage1 VMAX CAT/KAT EGR GPF/OPF
LAMBDA

DCM1.2

Stage1

DCM3.2

Stage1

DCM3.7

Stage1 VMAX DPF EGR FLAPS (Swirl) LAMBDA
Immo Off (FLASH)

DCM6.2

Stage1 Adblue CAT/KAT DPF EGR LAMBDA

DCU17PC43

Adblue

EDC15

Stage1 Stage2

EDC15C2

Stage1 DPF

EDC15C3

Stage1 Stage2

EDC15C7

Stage1 Stage1+ Stage2 Stage3 VMAX DPF EGR
Immo Off (EPROM) Immo Off (FLASH)

EDC16C39

E85 Conversion Stage1 Stage1+ Stage2 VMAX
DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
Immo Off (FLASH)

EDC16CP34

Stage1

EDC17

Stage1 Torque Monitor VMAX EGR

EDC17C08

Stage1 Stage2 DPF EGR

EDC17C53

Stage1

EDC17C53-08

Stage1 Stage1+ Stage2 Stage3 Torque Monitor
VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA
Immo Off (FLASH)

EDC17C57

Pops&Bangs Stage1 Stage2 Torque Monitor VMAX
Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl)
LAMBDA NOX Start-Stop TVA Immo Off (FLASH)

EDC17CP14

Stage1 Stage2 Torque Monitor VMAX DPF EGR
FLAPS (Swirl) LAMBDA TVA Immo Off (FLASH)

M7.9.7

Stage1 CAT/KAT LAMBDA Immo Off (FLASH)

ME17.9

E85 Conversion Stage1 CAT/KAT LAMBDA

ME17.9.1

E85 Conversion

ME17.9.21

LAMBDA

MED17

Stage1

MED17.1.4

E85 Conversion

MED17.9.11-12

VMAX CAT/KAT LAMBDA

MED17.9.2X

CAT/KAT LAMBDA

MED17.9.8

E85 Conversion Pops&Bangs Stage1 Stage2 VMAX
CAT/KAT EVAP LAMBDA

MG7.9.8

Stage1 CAT/KAT LAMBDA Immo Off (FLASH)

MT38

CAT/KAT EVAP LAMBDA

MT86

CAT/KAT EVAP FLAPS (Swirl) LAMBDA Immo Off (FLASH)

SIM2K

Pops&Bangs Stage1 CAT/KAT EVAP FLAPS (Swirl)
LAMBDA Immo Off (FLASH)

SIMK41

Stage1

Isuzu

5 ECU

DCU17PC43

Adblue

EDC17C83

Stage1 Stage1+ Torque Monitor Adblue DPF EGR

EDC17CV41

VMAX Adblue DPF EGR LAMBDA

SH7058

EGR

TRANSTRON

Stage1 Stage1+ VMAX DPF DTC Off EGR

Iveco

7 ECU

EDC16C39

Stage1 Stage1+ Stage2 DPF

EDC16C8

Stage1 Stage2 VMAX

EDC17C49

Stage1 Adblue DPF

EDC17C69

DPF

EDC17CP52

Stage1 DPF DTC Off EGR

EDC17U31

Adblue

EDC7UC31

Stage1 Stage2 Adblue

JAC

1 ECU

MD1CS089

Adblue DPF EGR

Lada

1 ECU

GEN832K

Stage1

Lamborghini

2 ECU

MED17.1.1

Stage2

MED9.1

Pops&Bangs Stage1

Land Rover - Jaguar

25 ECU

EDC15	Stage1	Stage2												
EDC15C4	Stage1	Stage1+	Stage2	Stage3										
EDC16CP39	Stage1	Stage2	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA							
EDC17	Stage1	DPF												
EDC17C08	Stage1	Stage2	DPF											
EDC17CP11	Stage1	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX				
EDC17CP42	Stage1	Stage1+	Torque Monitor	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	NOX					
EDC17CP55	Launch Control Activation	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	TVA
MED17	Stage1	Stage2	CAT/KAT	DPF	DTC Off	EGR								
MED17.0	Stage1													
MED17.1.9	Stage1													
MED17.5.4	Stage1	Stage2												
MED17.8.3	Stage1													
MED17.8.31	Stage1	Stage2												
MED17.8.32	Stage2													
MED17.8.3X	Pops&Bangs	Stage1	CAT/KAT	DTC Off	GPF/OPF	LAMBDA								
MED17.9.7-17.9.9	Exhaust Valve OFF	Launch Control Activation	Stage1	CAT/KAT	EVAP	LAMBDA								
MED17.9.9	Stage2													
MED172	Stage1													
MEDC17.9	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	TVA
MEDC179	Stage1													
SID201-04	Stage1	Stage1+	Stage2	VMAX	Adblue	DPF	DTC Off	EGR						
SID204	Stage1													
SID208	Stage1	DPF	EGR											
SID20X	Stage1													

MG

6 ECU

EDC17C06	Stage1
EDC17C54	Stage1
EDC17CP02	Stage1
GEN2048K	Stage1
GEN824K	Stage1
MED17	Stage1

Mahindra

4 ECU

EDC17C53	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA
EDC17C55	Torque Monitor	VMAX	DPF	EGR	
EDC17C81	VMAX	Adblue	DPF	EGR	

MD1CS018

Adblue EGR

Maserati

5 ECU

EDC17C79	Stage1					
ME7.1.3	Stage1					
ME7.3.2	Stage1					
MED17.3.4	Stage1					
MED17.3.X	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	LAMBDA

Maxus - LDV

2 ECU

EDC17C53	DPF	EGR	
EDC17C81	DPF	EGR	LAMBDA

Mazda

7 ECU

CX SER (DIESEL)	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Adblue	DPF	EGR	LAMBDA	TVA
CX3	DPF										
EDC16C3	Stage1	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	TVA				
EDC16C34	Stage1	DPF	DTC Off	EGR	Glow Plug						
EDC16C7	Stage1										
SID208	Stage1										
SKYACTIV-G	Stage1	Stage1+									

Mercedes

67 ECU

CRD11	Stage1																
CRD11 (DCM3.2)	Stage1	Stage1+	Torque Monitor	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA								
CRD2	Stage1	DPF	DTC Off														
CRD2.X	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA					
CRD3	Stage1	Stage2	Adblue	DPF													
CRD3.2R	Stage1																
CRD3.4	DPF																
CRD3.X	Exhaust Valve OFF	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	NOX	Start-Stop	TVA	
CRV2.0	EGR																
DCM3.2	Stage1																
EDC15	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	MAF	TVA				
EDC15C12	Stage1																
EDC15C2	Stage1																
EDC15C5	Stage1	Stage2															
EDC15C6	Stage1	Stage2	EGR														
EDC16	Gearbox Tuning	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	DPF	DTC Off	EGR	EGT Off	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	TVA	Immo Off (FLASH)

EDC16C0	Stage1
EDC16C2	DPF FLAPS (Swirl)
EDC16C31	E85 Conversion Stage1 Stage2 VMAX DPF DTC Off EGR TVA
EDC16C31-CP31	Stage1 Stage1+ Stage2 Stage3 VMAX DPF EGR FLAPS (Swirl) LAMBDA MAF Readiness Calibration TVA
EDC16C32	Stage1 Stage2 VMAX DPF EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16C36	Stage1
EDC16C39	Stage1
EDC16C6	Stage1
EDC16CP31	E85 Conversion Stage1 Stage2 Adblue DPF DTC Off FLAPS (Swirl) TVA
EDC16CP36	E85 Conversion Stage1 Stage2 Stage3 VMAX DPF EGR FLAPS (Swirl) LAMBDA MAF Readiness Calibration TVA
EDC17C01	Stage1 Adblue
EDC17C42	Stage1
EDC17C43	Stage1
EDC17C43-CP46	Stage1 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA
EDC17C66	E85 Conversion Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop
EDC17CP01	Stage1 Torque Monitor VMAX DPF EGR FLAPS (Swirl) LAMBDA Readiness Calibration
EDC17CP10	Stage1 Stage1+ Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration TVA
EDC17CP46	E85 Conversion Stage1 Stage2 VMAX Adblue DPF DTC Off EGR
EDC17CP57	Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA
MD1CP001	Stage1 Stage1+ Torque Monitor Adblue CAT/KAT DPF EGR FLAPS (Swirl) LAMBDA NOX Start-Stop TVA
MD1CS006	Stage1 Torque Monitor Adblue DPF EGR NOX
ME12	Stage1
ME17.7.X	E85 Conversion
ME2.0	E85 Conversion Stage1
ME2.7	Stage1
ME2.7.2	Stage1 VMAX
ME2.8	E85 Conversion Stage1
ME2.8.1	E85 Conversion Stage1
ME2.8.X	Stage1 Stage1+ VMAX CAT/KAT EGR LAMBDA
ME9.7	E85 Conversion Pops&Bangs RPM Soft Limiter Removal Stage1 Stage1+ Stage2 VMAX CAT/KAT DTC Off EGR FLAPS (Swirl) LAMBDA
MED17	E85 Conversion Pops&Bangs Stage1 Stage2 VMAX CAT/KAT DPF DTC Off EGR
MED17.	E85 Conversion Pops&Bangs Stage1 CAT/KAT LAMBDA

MED17.2	E85 Conversion
MED17.2.2	E85 Conversion
MED17.4	E85 Conversion
MED17.7	E85 Conversion Pops&Bangs Stage1 Stage2 CAT/KAT LAMBDA
MED17.7.	E85 Conversion CAT/KAT
MED17.7.1	E85 Conversion Stage1 Stage2
MED17.7.2	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX CAT/KAT EVAP FLAPS (Swirl) LAMBDA NOX
MED17.7.3	E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX CAT/KAT FLAPS (Swirl) LAMBDA NOX
MED17.7.5	E85 Conversion Pops&Bangs Stage1 Stage2
MED17.7.X	E85 Conversion Exhaust Valve OFF Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX CAT/KAT DPF DTC Off EVAP FLAPS (Swirl) LAMBDA NOX
MED1772	E85 Conversion
MED7.7.2	E85 Conversion
MED9.7	E85 Conversion Stage1
MEV17.2.2	E85 Conversion
MG1CP002	Pops&Bangs Stage1 Stage1+ Torque Monitor CAT/KAT DTC Off GPF/OPF LAMBDA
SID307	Stage1 Torque Monitor VMAX DPF EGR LAMBDA
SID310	Stage1 Stage1+ Torque Monitor VMAX Adblue DPF EGR LAMBDA NOX Start-Stop TVA
SIM271	Pops&Bangs Stage1 Stage1+ Stage2 Stage3 CAT/KAT DTC Off LAMBDA
TEMIC	Stage1 EGR

Mitsubishi10 ECU

EDC15C2	Stage1
EDC16C31	Stage1
EDC16C31-EDC7C4	DPF EGR MAF
EDC16C34	Stage1
EDC16CP3	Stage1
EDC16CP39	Stage1 Stage2 DTC Off TVA
EDC16U31	Stage1 Stage1+ Stage2 DPF EGR TVA
EDC17C49	Stage1 VMAX Adblue DPF EGR LAMBDA NOX TVA
EDC17CP15	Stage1 Torque Monitor Adblue DPF EGR FLAPS (Swirl) LAMBDA NOX
EDC17CP52	Stage1 Torque Monitor VMAX Adblue DPF EGR FLAPS (Swirl) NOX Immo Off (FLASH)

Opel - Chevrolet - Vauxhall62 ECU

DCM3	Stage1
DCM3.7	Stage1 DPF EGR FLAPS (Swirl) LAMBDA TVA
DCM7.1	VMAX Adblue DPF EGR LAMBDA NOX Start-Stop
DELCO E37	CAT/KAT EVAP LAMBDA
DELCO E38	Stage1 CAT/KAT EVAP LAMBDA

DELCO E39	Pops&Bangs	Stage1	CAT/KAT	EVAP	LAMBDA
DELCO E78	Stage1	CAT/KAT	LAMBDA		
DELCO E80-E84	Stage1	CAT/KAT	LAMBDA		
DELCO E83	Stage1	Stage1+	CAT/KAT	EGR	LAMBDA
DELCO E87	Pops&Bangs	Stage1	DPF	EGR	FLAPS (Swirl) LAMBDA
DELCO E92	Stage1	CAT/KAT	DPF	LAMBDA	
DELCO E98	Stage1	Stage2	VMAX	Adblue	DPF EGR
	FLAPS (Swirl)	LAMBDA	NOX	TVA	
E98	Stage1				
EDC15	Stage1	Stage1+	Stage2	Stage3	DPF EGR MAF
EDC15C2	Stage1				
EDC15C4	Stage1				
EDC15C7	Stage1				
EDC15V	Stage1				
EDC15VM	Stage1	Stage2	DPF	EGR	
EDC16C3	Stage1	Adblue			
EDC16C36	E85 Conversion	Stage1	VMAX	DPF	DTC Off EGR
EDC16C39	E85 Conversion	Hotstart	Stage1	Stage1+	Stage2
	Stage3	VMAX	Adblue	DPF	DTC Off EGR
	FLAPS (Swirl)	MAF	TVA		
EDC16C9	E85 Conversion	Hotstart	Stage1	Stage1+	Stage2
	Stage3	VMAX	DPF	DTC Off	EGR FLAPS (Swirl)
	LAMBDA	MAF	TVA		
EDC16CP33	Stage1	Stage2	VMAX	DPF	DTC Off EGR TVA
EDC17	Stage1	VMAX	Adblue	DPF	
EDC17C01	Stage1				
EDC17C11	Stage1	Torque Monitor	VMAX	DPF	EGR LAMBDA
EDC17C18	Stage1	Stage2	EGR		
EDC17C18-C19	Stage1	Stage1+	Stage2	Torque Monitor	VMAX
	DPF	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA TVA
EDC17C19	Stage1	Stage2	DPF		
EDC17C42	Stage1	Stage2	Torque Monitor	VMAX	DPF EGR
EDC17C59	Stage1	Stage1+	Stage2	Torque Monitor	VMAX
	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA
EDC17C60	Stage1				
EDC17C84	Torque Monitor	VMAX	Adblue	DPF	EGR LAMBDA
	NOX	Start-Stop	TVA		
EDC17CP47	Stage1	Torque Monitor	Adblue	DPF	EGR
	FLAPS (Swirl)	LAMBDA	TVA		
EMS040	DTC Off				
MD1CS003	Stage1	Torque Monitor	VMAX	Adblue	DPF DTC Off
	EGR	FLAPS (Swirl)	LAMBDA	Start-Stop	TPROT
ME1.5.5	Stage1	Stage1+	Stage2	Stage3	CAT/KAT EGR
	LAMBDA				
ME17.8.8	CAT/KAT	EVAP	LAMBDA		
ME3.1.1	Stage1				
ME7.6.2	E85 Conversion	Stage1	Stage2		
ME7.6.3	Stage1	Stage2			
ME7.6.4	Stage1				
ME7.6.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	
	Stage2	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl) LAMBDA

ME7.9.9	Stage1							
ME9	Stage1							
ME9.1	Stage1							
ME9.5	Stage1							
ME9.6	Stage1	Stage2	DTC Off					
ME9.6.1	Stage1							
MED9	Stage1							
MED9.6.1	Stage1							
MG1CS042	Stage1							
MJD602-3	HardCut	Stage1	Stage1+	Stage2	Adblue	DPF	EGR	MAF
MS56	Stage1							
MT35	Stage1	Stage2	Stage3	CAT/KAT	DTC Off	EGR	EVAP	LAMBDA
MT80	CAT/KAT	LAMBDA						
PSG16	Stage1	DPF	DTC Off	EGR	FLAPS (Swirl)	TVA		
SH7059	Stage1							
SID310	Stage1							
SIMTEC 7.5	Stage1	CAT/KAT	LAMBDA					
SIMTEC76	Stage1	CAT/KAT	EGR	LAMBDA				

PSA

84 ECU

DCM3.4	Stage1	Stage2	DPF	EGR	NOX	Immo Off (EPROM)
DCM3.5	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	
	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA MAF
	TVA					
DCM6.2	E85 Conversion	Stage1	Stage1+	Torque Monitor		
	VMAX	Adblue	DPF	EGR	LAMBDA	NOX
	Start-Stop					
	TVA	Immo Off (EPROM)				
DCM7	Adblue	DPF				
DCM7.1	Stage1	Stage1+	Stage3	Torque Monitor	VMAX	
	Adblue	DPF	DTC Off	EGR	LAMBDA	NOX
DCU102	Stage1	DPF	EGR			
DDCR	Stage1	EGR				
EDC15	Stage1	Stage2	VMAX	DPF	EGR	MAF
EDC15C	Stage1					
EDC15C2	Stage1	Stage2	VMAX	DPF	EGR	Immo Off (EPROM)
	Immo Off (FLASH)					
EDC15C3-C7	Stage1	Stage2	CAT/KAT	EGR	MAF	Immo Off (FLASH)
EDC15C6	Stage1					
EDC15C7	Stage1					
EDC16	Stage1	Stage2	DPF			
EDC16C0	Stage1					
EDC16C3	Stage1	Stage1+	Stage2	VMAX	DPF	EGR
	Glow Plug	LAMBDA	TVA			
EDC16C31	Stage1	DPF				
EDC16C32	Stage1					
EDC16C34	E85 Conversion	Pops&Bangs	Stage1	Stage1+		
	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF
	DTC Off	EGR	FLAPS (Swirl)	Glow Plug	LAMBDA	MAF
	TVA	Immo Off (FLASH)				

EDC16C39	Stage1	Stage2	VMAX	DPF	EGR	LAMBDA	MAF
	TVA						
EDC16CP34	Stage1						
EDC16CP36	Stage1						
EDC16CP39	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	
	FLAPS (Swirl)	LAMBDA	MAF	TVA			
EDC16U31	Stage1						
EDC17	Stage1	DPF	MAF				
EDC17C09	Stage1	DPF					
EDC17C10	Stage1	Stage1+	Torque Monitor	VMAX	Adblue	DPF	
	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration		
	Start-Stop	TVA	Immo Off (FLASH)				
EDC17C42-CP42	Stage1	Stage1+	Torque Monitor	DPF	DTC Off	EGR	
	FLAPS (Swirl)	LAMBDA	TVA				
EDC17C60	E85 Conversion	Stage1	Stage1+	Torque Monitor			
	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	
	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration			
	Start-Stop	TVA	Immo Off (FLASH)	TPROT			
EDC17CP04	Stage1						
EDC17CP11	Stage1	Torque Monitor	DPF	EGR			
EDC17CP14	Stage1						
EDC17CP42	Stage1						
EDC17CP52	Stage1	Stage2	VMAX	DPF	EGR	LAMBDA	
M7.9.5	Torque Monitor	CAT/KAT	LAMBDA				
MD1CS003	Stage1	Torque Monitor	VMAX	Adblue	CAT/KAT	DPF	
	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop		
	Immo Off (FLASH)	TPROT					
ME17.4	E85 Conversion						
ME7	E85 Conversion	Stage1					
ME7.4.4	E85 Conversion	Stage1					
ME7.4.5	E85 Conversion	Stage1					
ME7.4.6	E85 Conversion						
ME7.4.7	E85 Conversion						
ME7.4.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA			
ME7.44	E85 Conversion						
ME7.5	E85 Conversion						
ME7.9.51	Stage1						
MED17	Stage1	Stage2	DPF	EGR			
MED17.4	E85 Conversion	Stage1					
MED17.4.2	E85 Conversion	Stage1					
MED17.4.4	E85 Conversion	Stage1	Stage2				
MED17.4.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+			
	Stage2	CAT/KAT	DTC Off	EGR	LAMBDA	MAF	
MED17.5.1	Stage1						
MED174	Stage1						
MED7.4.4	E85 Conversion						
MED9	Stage1						
MEV17	E85 Conversion	Stage1					
MEV17.4	E85 Conversion						
MEV17.4.2	E85 Conversion	Stage1					
MEV1742	E85 Conversion	Stage1					

MEVD17.2.2	Stage1									
MEVD17.4.2	Stage1									
MEVD17.4.4	Stage1	Stage2	MAF							
MG1CS042	Stage1	VMAX	DTC Off	GPF/OPF						
MJ8	Stage1	DPF	EGR							
SID201	Stage1	Stage1+	Stage2	DPF	EGR	LAMBDA				
SID206	Stage1									
SID208	Pops&Bangs	Stage1	Stage2	VMAX	DPF	DTC Off	EGR	LAMBDA		
SID80	Stage1									
SID801	Stage1									
SID801-804	Pops&Bangs	Stage1	Stage1+	Stage2	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	
SID801A	Stage1									
SID801X	Stage1									
SID803	E85 Conversion	Stage1	DPF	DTC Off						
SID803-803A	Stage1	Stage1+	Stage2	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA
SID803A	Stage1	DPF								
SID804	Stage1	EGR								
SID805	EGR									
SID806	E85 Conversion	Stage1	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA			
SID807	Stage1	DPF	EGR							
SID807-807EVO	Stage1	Stage1+	VMAX	DPF	DTC Off	EGR	LAMBDA	Start-Stop	TVA	Immo Off (FLASH)
SID80X	Stage1	DPF								
TEST YAZAN	Torque Monitor	Adblue	DPF							
V46	E85 Conversion	Stage1	CAT/KAT	DTC Off	LAMBDA					
VD56	E85 Conversion	Stage1	CAT/KAT	LAMBDA						

Porsche

11 ECU

EDC17CP14	Stage1						
EDC17CP44	Stage1	Stage2	VMAX	Adblue	DPF	EGR	Start-Stop
ME7	Stage1						
ME7.1.1	Stage1						
ME7.2	Stage1						
ME7.8	Stage1	Stage2	LAMBDA				
ME7.8.2	Stage1						
MED17.1	Stage2						
MED17.1.1	Stage2						
MED17.1.11	Stage1	Stage2					
MED9.1	Stage1						

RENAULT

1 ECU

S3000 **E85 Conversion**

Renault - Dacia - Nissan

55 ECU

DCM1.2 Stage1 Stage2

DCM3.4	Stage1	VMAX	DPF	EGR										
DCM3.7	DPF	EGR												
DDCR-DCM1.2	Boost Increase	Stage1	Stage1+	Stage2	VMAX	DPF	EGR	TVA						
EDC15	Stage1	Stage2												
EDC15C	Stage1													
EDC15C13	Stage1+	EGR												
EDC15C2	Stage1	DPF												
EDC15C3	Stage1	Stage1+	Stage2	Stage3	VMAX	DTC Off	EGR	MAF						
EDC15V	Stage1													
EDC16	Stage1													
EDC16C3	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	DPF	EGR							
EDC16C36	E85 Conversion	Stage1	VMAX	DPF	DTC Off	EGR	TVA							
EDC16C41	E85 Conversion	Stage1	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration						
EDC16CP33	E85 Conversion	Stage1	Stage1+	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA	Immo Off (FLASH)	
EDC16CP42	Stage1	Stage2	VMAX	Adblue	DPF	DTC Off	EGR	TVA						
EDC17	Stage1	VMAX	Adblue	DPF	DTC Off	FLAPS (Swirl)								
EDC17C11	Exhaust Valve OFF	Stage1	Stage2	VMAX	DPF	EGR	LAMBDA	TVA						
EDC17C42	E85 Conversion	Exhaust Valve OFF	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	TVA	
EDC17C45	Exhaust Valve OFF	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA	TVA						
EDC17C84	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Start-Stop	TVA	Immo Off (FLASH)
EDC17CP11	Stage1	VMAX	DPF	EGR	FLAPS (Swirl)									
EDC17CP19	Stage1	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA							
EDC17CP58	Exhaust Valve OFF	Stage1	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA							
EMS2	Stage1													
EMS2.2	Adblue													
EMS3	Stage1													
EMS3110	E85 Conversion	Exhaust Valve OFF	Launch Control Activation	Pops&Bangs	Stage1	VMAX	CAT/KAT	DPF	EVAP	LAMBDA				
EMS3125	Stage1	CAT/KAT	EVAP	LAMBDA										
EMS3130	Stage1													
EMS3132	Stage1													
EMS314X	E85 Conversion	Stage1	Adblue	CAT/KAT	EVAP	GPF/OPF	LAMBDA							
EMS3150	Stage1													
EMS3155	E85 Conversion	Stage1	Stage2											

EMS315X	E85 Conversion	Exhaust Valve OFF	Pops&Bangs	Stage1	Torque Monitor	VMAX	CAT/KAT	DTC Off	EVAP	LAMBDA		
EMS3160	CAT/KAT	EVAP	GPF/OPF	LAMBDA								
EMS3161	CAT/KAT	EVAP	GPF/OPF	LAMBDA								
MAXITY	Stage1+											
MD1CS006	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	DPF	EGR	LAMBDA	TVA			
MD1CS016	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA						
ME17.9.23	CAT/KAT	LAMBDA										
MEC93	Stage1											
S3000	E85 Conversion	Stage1	CAT/KAT	LAMBDA								
SID301	Stage1	EGR										
SID301-04	Stage1	DPF	EGR	TVA								
SID305	Stage1	DPF	DTC Off	EGR								
SID305-6	Stage1	Stage1+	Stage2	VMAX	DPF	DTC Off	EGR	LAMBDA	TVA			
SID306	Stage1	DPF										
SID307	Stage1	Torque Monitor	Adblue	DPF	EGR	LAMBDA	TVA					
SID309	Exhaust Valve OFF	Stage1	VMAX	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA				
SID310	Exhaust Valve OFF	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	LAMBDA	NOX	Start-Stop	TVA
SID321	Stage1	Torque Monitor	VMAX	Adblue	DPF	EGR	LAMBDA	Start-Stop	TVA			
SIM32	Stage1	CAT/KAT	DTC Off	LAMBDA								
V42	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT	DPF	EVAP	LAMBDA				
V50	Stage1											

Renault Arkana	1 ECU
EMS3161	E85 Conversion

Rolls-Royce

1 ECU

GEN2048K

Stage1

Stage2

Saab	5 ECU
EDC16C39	Stage1
EDC16C9	Stage1
EDC17C19	Stage1
EDC17CP21	Stage1
ME9.6	Stage1

Smart

7 ECU

EDC15

Stage1

Stage1+

Stage2

Stage3

VMAX

EGR

MAF

EDC15C5

Stage1

EDC16C31

Stage1

VMAX

EDC16C31-C32

Stage1

DPF

DTC Off

EGR

MAF

ME17.9.20	E85 Conversion	Stage1	CAT/KAT	LAMBDA	
ME7.7	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX
	CAT/KAT	DPF	LAMBDA	TVA	
ME7.7.0	Stage1				

SsangYong

4 ECU

DCM3.2

Stage1

DPF

EGR

DCM3.7

Stage1

DPF

EGR

FLAPS (Swirl)

DCM6.2

Stage1

VMAX

Adblue

DPF

EGR

LAMBDA

DCM6.X

Stage1

Suzuki

15 ECU

DCM1.2

Stage1

EDC15

Stage1

Stage2

EDC15C2

Stage1

EGR

EDC16C3

Stage1

VMAX

DPF

EGR

TVA

EDC16C36

Stage1

DPF

EGR

EDC16C39

Stage1

DPF

EGR

EDC17C49

Stage1

Torque Monitor

DPF

EGR

FLAPS (Swirl)

LAMBDA

TVA

ME17

Stage1

ME17.9.6X

E85 Conversion

Pops&Bangs

Rev Limiter Raise

Stage1

Stage2

VMAX

CAT/KAT

LAMBDA

MED17

Stage1

MED17.9.63

Stage1

Stage2

MJD6J0

DPF

EGR

MAF

MJD8DS

Stage1

Adblue

DPF

DTC Off

EGR

LAMBDA

MAF

MM8GSW

Stage1

SIMOS3.X

EGR

TOYOTA1 ECU	
EDC15C9	EGR

Tata

1 ECU

EDC17C69

Stage1

Adblue

DPF

Toyota - Lexus242 ECU	
89663-02E73	Stage1
89663-02G31	Stage1
89663-02G32	Stage1
89663-02G40	Stage1
89663-02G41	Stage1
89663-02G42	Stage1
89663-02J22	Stage1
89663-02X72	Stage1
89663-06A31	Stage1
89663-06A35	Stage1
89663-06A41	Stage1

89663-06A45	Stage1
89663-06B40	Stage1
89663-06D40	Stage1
89663-06E72	Stage1
89663-06E82	Stage1
89663-06F51	Stage1
89663-06N42	Stage1
89663-06N61	Stage1
89663-0C330	Stage1
89663-0C572	Stage1
89663-0C582	Stage1
89663-0C592	Stage1
89663-0C601	Stage1
89663-0C710	Stage1
89663-0C821	Stage1
89663-0C831	Stage1
89663-0C841	Stage1
89663-0C850	Stage1
89663-0C851	Stage1
89663-0C852	Stage1
89663-0C891	Stage1
89663-0CA01	Stage1
89663-0CA11	Stage1
89663-0CA21	Stage1
89663-0CA31	Stage1
89663-0CA41	Stage1
89663-0CA51	Stage1
89663-0CA61	Stage1
89663-0CA71	Stage1
89663-0CA81	Stage1
89663-0CA91	Stage1
89663-0CB01	Stage1
89663-0CC31	Stage1
89663-0CD70	Stage1
89663-0CJ54	Stage1
89663-0CL10	Stage1
89663-0E142	Stage1
89663-0F097	DPF EGR
89663-0F098	DPF EGR
89663-0K121	Stage1 EGR
89663-0K222	Stage1 EGR
89663-0K223	EGR
89663-0K242	EGR
89663-0K873	EGR
89663-0KK91	EGR
89663-0KK93	EGR
89663-0KM60	EGR
89663-0KM61	EGR
89663-0KM63	EGR

89663-0T070	Stage1
89663-0T121	Stage1
89663-0T160	Stage1
89663-0T220	Stage1
89663-30B02	Stage1
89663-30B10	Stage1
89663-30B11	Stage1
89663-30C02	Stage1
89663-30C51	Stage1
89663-30E00	Stage1
89663-30E70	Stage1
89663-30F51	Stage1
89663-30G01	Stage1
89663-30K81	Stage1
89663-30N40	Stage1
89663-30S31	Stage1
89663-33A50	Stage1
89663-33A51	Stage1
89663-33A53	Stage1
89663-33A60	Stage1
89663-33A61	Stage1
89663-33A70	Stage1
89663-33A71	Stage1
89663-33A72	Stage1
89663-33A74	Stage1
89663-33B51	Stage1
89663-33B52	Stage1
89663-33B60	Stage1
89663-33D30	Stage1
89663-33D71	Stage1
89663-33E90	Stage1
89663-33F41	Stage1
89663-33G81	Stage1
89663-33J92	Stage1
89663-33K10	Stage1
89663-33M22	Stage1
89663-33M42	Stage1
89663-42A33	Stage1
89663-42B82	Stage1
89663-42C72	Stage1
89663-42E70	DPF EGR
89663-42F11	Stage1
89663-42F13	Stage1
89663-42F40	Stage1
89663-42L90	Stage1
89663-42M20	Stage1
89663-42M21	Stage1
89663-42N52	Stage1
89663-42N62	Stage1

89663-42Q11	Stage1
89663-42Q21	Stage1
89663-48A01	Stage1
89663-48C10	Stage1
89663-48C30	Stage1
89663-48G00	Stage1
89663-48M50	Stage1
89663-50A90	Stage1
89663-50B91	Stage1
89663-52D02	Stage1
89663-52D30	Stage1
89663-52F01	Stage1
89663-52J01	Stage1
89663-60A31	EGR
89663-60A32	EGR
89663-60A33	EGR
89663-60A34	EGR
89663-60A60	EGR
89663-60A63	EGR
89663-60A70	EGR
89663-60A71	EGR
89663-60A72	EGR
89663-60A73	EGR
89663-60A80	EGR
89663-60A82	EGR
89663-60A83	EGR
89663-60B03	EGR
89663-60B30	EGR
89663-60B81	Stage1
89663-60C00	Stage1
89663-60C01	Stage1
89663-60C02	Stage1
89663-60C03	Stage1
89663-60C21	Stage1
89663-60C22	Stage1
89663-60C26	Stage1
89663-60C30	Stage1
89663-60C32	Stage1
89663-60C34	Stage1
89663-60C35	Stage1
89663-60C51	Stage1
89663-60D00	Stage1
89663-60E10	Stage1
89663-60E62	Stage1
89663-60E64	Stage1
89663-60E70	Stage1
89663-60E72	Stage1
89663-60E74	Stage1
89663-60E80	Stage1

89663-60F32	Stage1
89663-60F42	Stage1
89663-60F52	Stage1
89663-60F91	Stage1
89663-60F92	Stage1
89663-60G00	EGR
89663-60G01	EGR
89663-60G02	EGR
89663-60G03	EGR
89663-60G62	Stage1
89663-60G92	DPF EGR
89663-60J01	EGR
89663-60J10	EGR
89663-60J20	EGR
89663-60J21	EGR
89663-60J30	EGR
89663-60J50	EGR
89663-60J80	EGR
89663-60K01	Stage1
89663-60K40	DPF EGR
89663-60K41	DPF EGR
89663-60K60	EGR
89663-60K62	EGR
89663-60K90	EGR
89663-60K91	EGR
89663-60L20	EGR
89663-60L50	EGR
89663-60L70	Stage1
89663-60M00	Stage1
89663-60M30	Stage1
89663-60M50	Stage1
89663-60M90	EGR
89663-60N40	EGR
89663-60N41	EGR
89663-60N70	EGR
89663-60N71	EGR
89663-60N72	EGR
89663-60N73	EGR
89663-60N74	EGR
89663-60P10	EGR
89663-60P50	Stage1
89663-60P90	DPF EGR
89663-60Q00	Stage1
89663-60Q10	Stage1
89663-60Q60	Stage1
89663-60R00	EGR
89663-60U50	Stage1
89663-60U90	Stage1 DPF EGR
89663-60U91	DPF EGR

89663-60V20	EGR
89663-60V60	EGR
89663-60X26	Stage1 DPF EGR
89663-60Z31	Stage1
89663-6A160	Stage1
89663-F0305	Stage1
89663-F0593	Stage1
89663-YWF06	Stage1
89663-YWF14	Stage1
89663-YWF18	Stage1
89663-YWF25	Stage1
89663-YWF28	Stage1
89663-YWF29	Stage1
89663-YWF34	Stage1
89663-YWL01	Stage1
89663-YWL09	Stage1
89663-YWL11	Stage1
89663-YWL19	Stage1
89663-YWL23	Stage1
DCM6.2	Stage1 Adblue DPF EGR NOX
DCM7.1	Stage1 Adblue DPF EGR
EDC15	Stage1
EDC15C9	Stage1 EGR
EDC16C10	Stage1 DPF EGR
EDC16C31	E85 Conversion Stage1 VMAX DPF EGR FLAPS (Swirl)
EDC17C01	Stage1
EDC17C47	Launch Control Activation DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17C60	Stage1 Adblue DPF
EDC17C73	Stage1 Torque Monitor DPF EGR FLAPS (Swirl) LAMBDA TVA
EDC17CP07	Stage1
EDC17CP07-CP37	Stage1 Torque Monitor VMAX DPF EGR FLAPS (Swirl) LAMBDA TVA
ME17.9.52	Stage1 CAT/KAT EGR LAMBDA
MG1CS201	Stage1
MG1CS201 (SUPRA)	CAT/KAT GPF/OPF LAMBDA
SID805	Stage1

VAG		259 ECU
CRD3.X	Adblue	
DCM3.5	Stage1	
DCM3.7	E85 Conversion Stage1 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA TVA Water Pump	
DCM6,2	Stage1	
DCM6.2	Exhaust Valve OFF Stage1 Stage1+ VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Start-Stop Water Pump	
DL501	Stage1	
DQ200	Stage1	

DQ200G2	Stage1
DQ250	Launch Control Activation Stage1 Stage1+
DQ381	Pops&Bangs Stage1
DQ38X	Stage1
DQ500	Stage1
DSG AL551	Stage1 Stage1+
EDC15	E85 Conversion Hotstart Launch Control Activation Pops&Bangs Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) MAF Multimap TVA
EDC15C	Stage1
EDC15C4	Stage1
EDC15C5	Stage1
EDC15C6	Stage1 Stage2
EDC15P	Stage1 Stage2 VMAX MAF
EDC15V	Stage1
EDC15VM	Stage1 Stage2 DPF
EDC15VMP	Stage1
EDC16	E85 Conversion Stage1 Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF
EDC16C0	Stage1 Stage2 DTC Off MAF
EDC16C1	Stage1
EDC16C10	Stage1
EDC16C2	Stage1
EDC16C3	Stage1
EDC16C31	E85 Conversion Stage1 Stage1+ Stage2 DPF DTC Off EGR FLAPS (Swirl) MAF
EDC16C32	E85 Conversion Stage1 Stage2 DPF
EDC16C34	E85 Conversion Stage1 Stage2 VMAX DPF EGR FLAPS (Swirl)
EDC16C35	Stage1 VMAX
EDC16C36	Stage1
EDC16C39	Stage1
EDC16C4	Stage1 Stage2 VMAX EGR
EDC16C7	Stage1
EDC16C8	Stage1
EDC16C9	Stage1
EDC16CAN	Stage1
EDC16CP31	E85 Conversion Stage1 Stage2 DPF
EDC16CP34	E85 Conversion Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA
EDC16CP35	Stage1
EDC16CP36	Stage1 Stage2 DPF
EDC16CP39	Stage1
EDC16CP42	Stage1
EDC16U1	E85 Conversion Gearbox Tuning HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (FLASH)
EDC16U2	Stage1 Stage2

EDC16U2.1	Stage1
EDC16U3	Stage1
EDC16U31	E85 Conversion HardCut Hotstart RPM Soft Limiter Removal Stage1 Stage1+ Stage2 Stage3 VMAX DPF DTC Off EGR EGT Off FLAPS (Swirl) LAMBDA MAF TVA Immo Off (EPROM)
EDC16U34	E85 Conversion HardCut Hot Start Fix Hotstart Stage1 Stage1+ Stage2 Stage3 VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF TVA Immo Off (EPROM)
EDC16UC40	Stage1
EDC16V2	Stage1 DPF EGR
EDC17	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 VMAX Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl)
EDC17121	Stage1
EDC17521	Stage1
EDC17C01	Stage1
EDC17C06	Stage1
EDC17C08	Stage1
EDC17C10	Stage1 DPF EGR
EDC17C18	Stage1
EDC17C19	Stage1
EDC17C41	Stage1
EDC17C42	DPF EGR
EDC17C43	Stage1
EDC17C43-CP46	Stage1
EDC17C46	E85 Conversion Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue CAT/KAT Decat DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C49	Stage1 DPF EGR LAMBDA TVA
EDC17C54	E85 Conversion Exhaust Valve OFF Stage1 Stage2 Stage3 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH)
EDC17C60	Stage1 Adblue DPF
EDC17C64	E85 Conversion Exhaust Valve OFF HardCut Pops&Bangs Stage1 Stage1+ Stage2 Torque Monitor VMAX Adblue DPF DTC Off EGR FLAPS (Swirl) LAMBDA MAF NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH) TPROT
EDC17C66	E85 Conversion Stage1
EDC17C69	Stage1
EDC17C74	E85 Conversion HardCut Stage1 Stage1+ Stage2 Torque Monitor VMAX Active Grill Shutter Adblue CAT/KAT DPF DTC Off EGR FLAPS (Swirl) LAMBDA NOX Readiness Calibration Start-Stop TVA Water Pump Immo Off (FLASH) TPROT
EDC17C79	Stage1
EDC17CP01	Stage1 DPF EGR
EDC17CP02	Stage1 DPF LAMBDA Readiness Calibration

EDC17CP04	E85 Conversion	HardCut	Stage1	Stage2	Torque Monitor	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA	Immo Off (FLASH)								
EDC17CP10	Stage1	Stage2	DPF	EGR																		
EDC17CP11	Stage1																					
EDC17CP14	E85 Conversion	HardCut	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	Decat	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Water Pump	Immo Off (FLASH)
EDC17CP20	E85 Conversion	Stage1	Stage1+	Stage2	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Water Pump	Immo Off (FLASH)				
EDC17CP24	Exhaust Valve OFF	Stage1	Stage2	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	LAMBDA	Readiness Calibration	TVA											
EDC17CP42	Stage1																					
EDC17CP44	E85 Conversion	Exhaust Valve OFF	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Immo Off (FLASH)	
EDC17CP46	Stage1	Stage2																				
EDC17CP54	Stage1	Stage2	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	LAMBDA	NOX	Oil Pressure Fix	Readiness Calibration	Start-Stop	TVA									
EDC17CP57	Stage1	Stage2	Adblue																			
EDC17CP74	E85 Conversion	Stage1	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Readiness Calibration	Start-Stop	TVA	Water Pump								
EDC17CV41	Stage1																					
EDC17CV52	Stage1																					
EDC17U01	Stage1	Stage2	DTC Off																			
EDC17U01-05	Stage1	Stage1+	Stage2	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA	TVA													
EDC17U05	Stage1																					
IAW4MV	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DPF	EGR	LAMBDA														
MD1CP001	Stage1																					
MD1CP004	Stage1	Torque Monitor	VMAX	Adblue	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	NOX	Oil Pressure Fix	Readiness Calibration	Start-Stop	TVA								
MD1CP014	Stage1	VMAX	Adblue	DPF	EGR	FLAPS (Swirl)	NOX	Start-Stop														
MD1CS004	Stage1	Stage1+	VMAX	Adblue	DPF	EGR	LAMBDA	NOX	Readiness Calibration	Start-Stop												
MD1CS006	Stage1	Adblue																				
MD1CS014	Stage1	Adblue	DPF	EGR	LAMBDA	Oil Pressure Fix	Start-Stop															
MDG1	Stage1																					
ME17	E85 Conversion	Stage1	TVA																			
ME17.5.2	E85 Conversion	Stage1	DTC Off	TVA																		
ME17.5.20	E85 Conversion	Stage1	DTC Off	TVA																		

ME17.5.20-26	Cylinder On Demand OFF	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	VMAX	CAT/KAT	DTC Off	EGR	EVAP	LAMBDA	Readiness Calibration	Immo Off (EPROM)	Immo Off (FLASH)				
ME17.5.24	Stage1																		
ME17.5.26	E85 Conversion																		
ME17.5.2X	Stage1																		
ME17.5.6	Pops&Bangs	Stage1	CAT/KAT	DTC Off	EVAP	LAMBDA	Readiness Calibration												
ME2.0	Stage1																		
ME2.7	Stage1																		
ME2.7.1	Stage1																		
ME2.7.2	Stage1																		
ME2.8	Stage1																		
ME2.8.1	Stage1	Stage2																	
ME3	Stage1																		
ME3.8	Stage1	Stage2	DPF																
ME3.8.1	Stage1																		
ME5.2	Stage1																		
ME5.9.2	Stage1																		
ME7	E85 Conversion	Stage1	Stage2																
ME7.1	E85 Conversion	Stage1	Stage2	Stage3	VMAX														
ME7.1-ME7.1.1	HardCut	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EVAP	LAMBDA						
ME7.1.1	E85 Conversion	Stage1	Stage2	Stage3	VMAX	Decat	LAMBDA												
ME7.1.5	Stage1																		
ME7.2	Stage1	Stage2																	
ME7.3.2	Stage1																		
ME7.5	Anti-Lag	E85 Conversion	Launch Control Activation	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	CAT/KAT	DPF	DTC Off	EGR	EVAP	LAMBDA	MAF	SAP
ME7.5.10	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	CAT/KAT	DTC Off	EGR	EVAP	LAMBDA									
ME7.8	E85 Conversion	Stage1	Stage2																
ME7.8.2	Stage1																		
ME9	Stage1	Stage2																	
ME9.1	Stage1	Stage2	VMAX																
ME9.1.1	Stage1	Stage2																	
ME9.5	Pops&Bangs	Stage1	Stage1+	Stage2	Adblue	DTC Off	EGR												
ME9.7	Stage1	Stage2																	
MED17	E85 Conversion	Pops&Bangs	Stage1	VMAX	CAT/KAT	DPF	EGR												
MED17.1	E85 Conversion	Exhaust Valve OFF	HardCut	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	Readiness Calibration	SAP	TVA	TPROT	

PCR2.1	E85 Conversion	HardCut	Launch Control Activation	Pops&Bangs	Stage1	Stage1+	Stage2	Stage3	VMAX	Adblue	Decat	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	Readiness Calibration	Start-Stop	TVA	Water Pump
PPD1.2	DPF																				
PPD1.X	Hotstart	Launch Control Activation	Stage1	Stage1+	Stage2	Stage3	VMAX	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA	MAF	TVA	Immo Off (FLASH)						
SDI10	VMAX	CAT/KAT	LAMBDA																		
SDI3	CAT/KAT	DPF	LAMBDA																		
SDI6-7-8-9	Stage1	Stage1+	Stage2																		
SDI6/7/8/9	Pops&Bangs	Stage1	Stage2	CAT/KAT	EVAP	LAMBDA															
SID3	Stage2																				
SID307	Stage1																				
SID310	DPF	EGR																			
SID9	Stage1	Stage2																			
SIM05	Stage1	Stage2	Immo Off (FLASH)																		
SIM0510	E85 Conversion	Stage1																			
SIM0510.1.0	Stage1																				
SIM0510.10	E85 Conversion	Stage1	Stage2	VMAX																	
SIM0510.12	Stage1																				
SIM0510.1X	E85 Conversion	Stage1																			
SIM0510.2	Stage1																				
SIM0510.22	Stage1																				
SIM0510.23	Stage1																				
SIM0510.24	Stage1																				
SIM0510.2X	E85 Conversion	Pops&Bangs	Stage1	Stage2																	
SIM0510.X	E85 Conversion	Pops&Bangs	Stage1	Stage1+	Stage2	VMAX	CAT/KAT	DPF	EGR	EVAP	FLAPS (Swirl)	LAMBDA	MAF	Start-Stop							
SIM0511.X	E85 Conversion	Pops&Bangs	CAT/KAT	EVAP	FLAPS (Swirl)	LAMBDA															
SIM0512	E85 Conversion	Pops&Bangs	Stage1	Stage2	CAT/KAT	DTC Off	TVA														
SIM0512.1	E85 Conversion	Pops&Bangs																			
SIM0512.2	E85 Conversion	Stage1																			
SIM0512.X	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage1+	Stage3	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA									
SIM0516.X	CAT/KAT	EVAP	LAMBDA	SAP																	
SIM0518	E85 Conversion	Pops&Bangs	Stage1	Stage2	VMAX	CAT/KAT	DTC Off														
SIM0518.1	E85 Conversion	Pops&Bangs	Stage1																		
SIM0518.10	E85 Conversion	Pops&Bangs	Stage1	Stage2	VMAX																
SIM0518.2	Stage1	DTC Off																			
SIM0518.4	Stage1																				
SIM0518.6	E85 Conversion																				

SIM0518.X	E85 Conversion	Exhaust Valve OFF	Launch Control Activation	Pops&Bangs	Pops&Bangs (Switchable)	RPM Soft Limiter Removal	Stage1	Stage1+	Stage2	VMAX	Active Grill Shutter	CAT/KAT	DPF	DTC Off	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	Readiness Calibration	SAP	Start-Stop	TVA	Immo Off (FLASH)
SIM0519.X	Pops&Bangs	Stage1	Stage1+	VMAX	CAT/KAT	EVAP	FLAPS (Swirl)	GPF/OPF	LAMBDA	SAP	Start-Stop	TVA											
SIM052	E85 Conversion	Stage1	Stage2																				
SIM053	E85 Conversion	Stage1	Stage2																				
SIM053.2	Stage1																						
SIM053.3	E85 Conversion																						
SIM053.X	E85 Conversion	Stage1	Stage2	CAT/KAT	EGR	LAMBDA																	
SIM0533	E85 Conversion																						
SIM054	Stage1																						
SIM056.2	E85 Conversion																						
SIM056.X	Stage1	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA																
SIM057.1	E85 Conversion	Stage1																					
SIM057.X	Pops&Bangs	Stage1	CAT/KAT	EGR	LAMBDA																		
SIM0571	Stage1																						
SIM058	E85 Conversion	Stage1																					
SIM058.2	E85 Conversion	Stage1																					
SIM058.3	Stage1																						
SIM058.4	E85 Conversion	Stage1	Stage2	VMAX	DTC Off	LAMBDA																	
SIM058.5	E85 Conversion	Stage1	Stage2	TVA																			
SIM058.X	E85 Conversion	Pops&Bangs	RPM Soft Limiter Removal	Stage1	Stage2	Stage3	VMAX	CAT/KAT	DTC Off	EVAP	FLAPS (Swirl)	LAMBDA	SAP	TVA									
SIM059.1	E85 Conversion	Stage1																					
SIM059.X	E85 Conversion	Stage1	CAT/KAT	LAMBDA																			
SIM0591	E85 Conversion																						
TEMIC	Stage1	Stage2	DPF																				

Voge	1 ECU
MSE6_0	VMAX

Volvo

31 ECU

(VEA-VED) VERSION1

Stage1

DPF

EGR

FLAPS (Swirl)

LAMBDA

EDC15

E85 Conversion

Stage1

Stage2

EGR

EDC15C11

Stage1

EGR

EDC15C2

Stage1

Stage2

EDC15C3

Stage1

EDC15VM

Stage1

EDC16

Stage1

Stage2

DPF

MAF

EDC16C31

E85 Conversion

Stage1

Stage1+

Stage2

Stage3

VMAX

DPF

DTC Off

EGR

FLAPS (Swirl)

MAF

TVA

EDC16C34	E85 Conversion	Stage1	Stage2	VMAX	DPF	EGR	MAF
EDC17CP22	Stage1	Torque Monitor	DPF	DTC Off	EGR	FLAPS (Swirl)	LAMBDA
EDC17CP48	Stage1	Stage2	Torque Monitor	DPF	DTC Off	EGR	LAMBDA Immo Off (FLASH)
EDC17CP68	Stage1	Torque Monitor	DPF	EGR	FLAPS (Swirl)	LAMBDA	
EMS2	E85 Conversion						
EMS2000	Stage1	DTC Off					
EMS22	DPF						
ME7	Stage1	Stage2					
ME7.0	E85 Conversion	Stage1	Stage1+				
ME7.0.1	Stage1	LAMBDA					
ME9	Stage1	Stage2					
ME9.0	Stage1						
ME9.0C	Stage1	Stage1+	Stage2	Stage3	CAT/KAT	LAMBDA	
ME9.7	Stage1						
MED17	Stage1	Stage2					
MED17.0	Stage1	VMAX	LAMBDA	MAF			
MED17.1.9	Stage1						
MG1CS080	Stage1	CAT/KAT	EVAP	LAMBDA			
SID206	DPF	DTC Off	EGR				
SID803	Stage1	DPF					
SID803A	Stage1	VMAX	DPF	EGR			
SID807	Stage1						
SID807-807EVO	Stage1	VMAX	DPF	EGR			
lexus toyota1 ECU							
EDC15C9	Stage1						
renault1 ECU							
VALEO	CAT/KAT						
vw1 ECU							
MED9.1	Immo Off (FLASH)						